


BREAKDOWN HT-40



REFERENCE	DESCRIPTION
05BM3002010	KIT Ø9.7 STRUCTURAL
05BM3002010	KIT Ø6.5 STRUCTURAL
05BM3002021	KIT Ø4.8 BRALOCK
05BM3002022	KIT Ø6.4 BRALOCK
05BM3002023	KIT Ø4.8 UNILOCK
05BM3002024	KIT Ø6.4 UNILOCK
05BM3002025	KIT Ø8.0 UNILOCK
05BM3002026	KIT Ø10.0 UNILOCK
05BM3002027	KIT Ø6.4 ESTRUBOLT
05BM3002028	KIT Ø8.0 ESTRUBOLT

N°	REFERENCE	DESCRIPTION
1	05BM3002101	TRACTION PISTON
2	05BM3002102	TRACTION SLEEVE RETAINER
3	05BM3002103	TRACTION SLEEVE RETAINER PIN
4	05BM3002104	OIL WASHER (2 PCS.)
5	05BM3002105	OIL DRAIN SCREW (2 PCS.)
6	05BM3002106	SPRING
7	05BM3002107	GUIDE BOX
8	05BM3002108	REAR PLUG SEAL
9	05BM3002109	REAR PLUG JOINT
10	05BM3002110	REAR PLUG PIN
11	05BM3002111	RUBBER PROTECTION
12	05BM3002112	REAR PLUG
13	05BM3002113	DRIVE SHAFT SEAL
14	05BM3002114	HYDRAULIC CONNECTOR WASHER
15	05BM3002115	HYDRAULIC CONNECTOR
16	05BM3002116	TRIGGER BOARD
17	05BM3002117	MAIN SECTION
18	05BM3002118	TRIGGER SPRING
19	05BM3002119	TRIGGER GUIDE
20	05BM3002120	TRIGGER
21	05BM3002121	AIR CONNECTOR
22	05BM3002122	TUBE PROTECTION